





Unit : mm



Installation Manual:

- 1 The $\varnothing 25$ mm PVC tube for AC 220V or AC 110V Power wire (3 X $\varnothing 2.0$ mm).
- 2 The tube for RS485 wire (2 X $\varnothing 0.5$ mm) , TCP/IP wire (8 core) , Manually opening the turnstile wire (4 X $\varnothing 0.3$ mm) . The signal wire length should be less than 100m .
- 3 It is PCB board part .
- 4 Fixing the equipment with M12 X 80mm expansive bolt .