



Unit : mm



Installation Manual:

- 1 The $\varnothing 25\text{mm}$ PVC tube for AC 220V or AC 110V Power wire (3 X $\varnothing 2.0\text{mm}$).
- 2 The tube for RS485 wire (2 X $\varnothing 0.5\text{mm}$), TCP/IP wire (8 core), Manually opening the turnstile wire (4 X $\varnothing 0.3\text{mm}$). The signal wire length should be less than 100m.
- 3 It is PCB board part.
- 4 Fixing the equipment with M12 X 90mm expansive bolt.

